

# Instructions

# OPERATION Scupper PLUG

## Step 1



Remove containment equipment from storage bin prior to fueling your vessel.

## Step 2



Insert sorbent pillows tightly into freeing ports - No Gaps! Secure pillows in place with wooden scupper boards.

## Step 3



Place spare pads/sorbent material around fuel fill to capture any fuel spilled on deck.

## Step 4



Place 5 gallon buckets under fuel tank vents.

## Step 5: Begin Fueling & Stay Alert!

## Step 6: Return Equipment to Storage Bin.

### Keep in Mind...

- State & federal oil pollution civil penalties may be reduced or waived if appropriate spill prevention measures are taken.
- Report missing, damaged or contaminated equipment to the dock.



Texas General Land Office  
Jerry Patterson, Commissioner  
P.O. Box 12873  
Austin, Texas 78711-2873  
[www.glo.state.tx.us](http://www.glo.state.tx.us)

### If You Spill Fuel:

- Secure fueling operation.
- Notify dock.
- Properly dispose of soiled sorbents.
- You are responsible for replacing soiled equipment.
- If fuel enters the water notify:

Texas General Land Office  
**1-800-832-8224**-24hr spill #  
U.S. Coast Guard  
**1-800-424-8802**